

## **MJ May Material Specialists Inc.**

America's Largest Self-Gripping Fastener Converters

### **RECOMMENDATIONS FOR USE**

In order to obtain the best results from the Pressure Sensitive Adhesive Tape on our Self-Gripping Fasteners, we recommend the following:

- 1 – Apply at temperature about 68 degrees F,
- 2 – Make sure the substrate is smooth, clean and is free of oil and dust,
- 3 – Remove the release liner and press into place with firm even pressure,
- 4 – Allow at least one hour before loading or disengaging the tape,
- 5 – Best performance will be obtained after 6 hours,
- 6 – Perform a preliminary test when the substrate is Vinyl or PVC.
- 7 – Insure that the bag is closed when the product is being stored.

If you need further assistance, please email MJ May Sales Assistance at [sales@mjmay.com](mailto:sales@mjmay.com)